RICS software

DATALOGIC GRYPHON GBT4100 WIRELESS SCANNER

To configure your scanner, please scan the barcodes on this sheet from top to bottom:

ENTER/EXIT PROGRAMMING MODE

Set Global Prefix

8

E

0

0

Set Global Suffix

0

D

ENTER/EXIT PROGRAMMING MODE

ENTER/EXIT PROGRAMMING MODE

Need help?

Email help@ricssoftware.com or call us at (800)-654-3123 ext. 1