


HP PRESENTATION SCANNER

To configure your scanner, please scan the barcodes on this sheet from top to bottom:



Enter



Prefix



1



F



Enter



Suffix



0



D



Enter



Enter

Need help?

Email help@ricssoftware.com or call us at (800)-654-3123 ext. 1