

HP WIRELESS BARCODE SCANNER

To configure your scanner, please scan the barcodes on this sheet from top to bottom:



Set Global Prefix



8



E



0



0



Set Global Suffix



0



D



Need help?

Email help@ricssoftware.com or call us at (800)-654-3123 ext. 1